

Introduction [\(Ask a Question\)](#)

The I/O Editor displays all assigned and unassigned I/O macros and their attributes in a spreadsheet-like format. Use the I/O Editor to view, sort, filter, select, and set I/O attributes of the SmartFusion[®] 2, IGLOO[®] 2, RTG4[™], or PolarFire[®] device.

The I/O attributes can be viewed by port name or by package pin. Click the Ports View tab to view I/O attributes by port name. Click the Pin View tab to view I/O attributes by pin name.

The I/O Editor provides the following views for I/O assignment and planning:

- Port View—I/O spreadsheet sorted by port name
- Pin View—I/O spreadsheet sorted by pin number
- Package View—Package pin graphical view of the device

Notes: The following views are also available:

- Memory View—I/O view specific to the memory interface
- IOD View—I/O view specific to the IOD Lane Controller interface
- XCVR View—I/O view specific to the transceiver interface
- Floorplanner View—Detailed cell-level device view of the entire chip
- Netlist Viewer - Hier View—Post-synthesis hierarchical view
- Netlist Viewer - Flat View—Post-compile flattened netlist view

Note: This user guide shows a PolarFire device in the example figures.

Table of Contents

Introduction.....	1
1. Invoking the I/O Editor.....	5
2. Port View.....	6
2.1. Port Name.....	6
2.2. Direction.....	6
2.3. I/O Standard.....	7
2.4. Pin Number.....	7
2.5. Locked.....	7
2.6. Macro Cell.....	7
2.7. Bank Name.....	7
2.8. User I/O Lock Down.....	7
2.9. I/O State in Flash*Freeze Mode.....	7
2.10. Clamp Diode.....	7
2.11. Resistor Pull.....	7
2.12. I/O Available in Flash*Freeze Mode.....	8
2.13. Use I/O Calibration from the Lane.....	8
2.14. Schmitt Trigger.....	8
2.15. Vcm Input Range.....	8
2.16. On-Die Termination.....	8
2.17. ODT Static.....	8
2.18. ODT Dynamic.....	8
2.19. ODT Value.....	9
2.20. ODT Imp (Ohm).....	9
2.21. Low Power Exit.....	9
2.22. Input Delay.....	9
2.23. Slew.....	10
2.24. Pre-Emphasis.....	10
2.25. Output Drive.....	10
2.26. Impedance.....	10
2.27. Output Load.....	10
2.28. Source Termination.....	10
2.29. Output Delay.....	10
3. Pin View.....	11
3.1. Pin Number.....	11
3.2. Port Name.....	11
3.3. Direction.....	11
3.4. Macro Cell.....	11
3.5. Bank Name.....	11
3.6. Function.....	12
3.7. Locked.....	12
3.8. User Reserved.....	12
3.9. Dedicated.....	12
3.10. Vref.....	12
3.11. User I/O Lock Down.....	12

3.12.	I/O State in Flash*Freeze Mode.....	12
3.13.	Clamp Diode.....	12
3.14.	Resistor Pull.....	13
3.15.	I/O Available in Flash*Freeze Mode.....	13
3.16.	Schmitt Trigger.....	13
3.17.	Vcm Input Range.....	13
3.18.	On-Die Termination.....	13
3.19.	ODT Static.....	13
3.20.	ODT Dynamic.....	14
3.21.	ODT Value.....	14
3.22.	ODT Imp (Ohm).....	14
3.23.	Low Power Exit.....	14
3.24.	Input Delay.....	14
3.25.	Slew.....	15
3.26.	Pre-Emphasis.....	15
3.27.	Output Drive.....	15
3.28.	Impedance.....	15
3.29.	Output Load.....	15
3.30.	Source Termination.....	15
3.31.	Output Delay.....	15
4.	Package View.....	17
5.	Interface—Specific I/Os and Views.....	18
5.1.	Interface—Specific I/O Views.....	18
6.	Memory Interface View.....	19
6.1.	Memory Type.....	19
6.2.	Edge_Anchors for Memory Placement.....	19
6.3.	Memory Interface View Columns.....	20
6.4.	Making I/O Assignments.....	21
6.5.	IO_PDC File.....	22
6.6.	Removing I/O Assignments.....	23
7.	XCVR View.....	25
7.1.	XCVR Interface I/O Assignment.....	27
7.2.	Direct Versus Cascaded Connection.....	27
7.3.	Reference Clock (REFCLK) I/O Assignments.....	29
7.4.	Transmit PLL Assignment.....	30
7.5.	Placement DRC Rules.....	31
8.	IOD View.....	35
8.1.	Generic I/O Assignments.....	35
8.2.	DRC Rules.....	36
9.	Floorplanner View.....	37
9.1.	Operating Modes.....	37
9.2.	Netlist Views.....	43
10.	Other I/O Editor Windows.....	46
10.1.	World View Window.....	46

10.2. Log Window.....	46
10.3. Object Window.....	46
10.4. Display Options Window.....	47
10.5. Properties Window.....	47
11. Export Physical Constraints (PDC).....	48
12. Appendix.....	49
12.1. MSS I/O Placement.....	49
12.2. Bank Settings.....	49
12.3. IOSTD Support per Type of Bank.....	49
12.4. Port IOSTD Settings.....	50
12.5. Updating the I/O Banks and IOSTD.....	51
12.6. Designs without an MSS Macro.....	51
12.7. Default Bank Settings.....	51
12.8. PDC Setting.....	51
12.9. PolarFire SOC MSS I/O Attributes.....	51
13. Revision History.....	53
Microchip FPGA Support.....	55
Microchip Information.....	55
Trademarks.....	55
Legal Notice.....	55
Microchip Devices Code Protection Feature.....	56

1. Invoking the I/O Editor [\(Ask a Question\)](#)

The design must be in the post-synthesis state before the I/O Editor can be invoked. A warning message appears if the I/O Editor is invoked in the pre-synthesis state.

The I/O Editor can be invoked in two ways from the Constraint Manager:


- **Design Flow window > Manage Constraints > Open Manage Constraints View > Constraint Manager > I/O Attributes > Edit > Edit with I/O Editor**
- **Design Flow window > Manage Constraints > Open Manage Constraints View > Constraint Manager > I/O Attributes > View**

The **Edit with I/O Editor** option in the Constraint Manager allows you to save or commit your changes to PDC files, whereas the **View** option shows the post-Place and Route design including the final placement and the I/O attributes in read-only mode. You cannot save or commit any changes made in the I/O Editor opened using the **View** option.

However, you can export and save the physical constraints using **File > Export Physical Constraint (PDC)** in both options and save them. These constraints can later be used in your design as input files, depending on the design's requirement.

The I/O Editor opens with view tabs across the top of the graphical interface, as shown in the following figure.

Figure 1-1. I/O Editor



2. Port View [\(Ask a Question\)](#)

The Port View displays the I/O attributes in a spreadsheet-like format. Each row corresponds to an I/O port in the design, sorted by the port name. The column headings specify the names of the I/O attributes in your design. The first few column headings are standard and common for all families. The remaining columns display family-specific attributes. Only attributes applicable to a specific device appear in the I/O Editor attributes table. For some I/O attributes, you will choose from a drop-down menu; for others, you might enter a value and for others, the field is read-only and not editable.

Displayed columns can be sorted alphabetically, numerically, or filtered.

In the I/O Editor, the ports can be viewed in a spreadsheet-like format or in the Design Tree View window of the Port tab. A port selected in the Port tab is also selected in the Port View spreadsheet and vice versa. The following figure shows the DM[0] selected in the spreadsheet and the Design Tree port view.

The Port View also displays the memory width and data rate of the DDR instance in the design (if it exists in the design) in the top left row under the Port Name column, as shown in the following figure.

Figure 2-1. Port View

Port Name	Direction	I/O Standard	Pin Number	Locked	Macro Cell	Bank Name	Used I/O Bits	User I/O Lock Down	Clamr Clock
1 A	INPUT	LVCMOS18	J5		INBUF	Bank4	None		ON
2 D	INPUT	LVCMOS18	U5		INBUF	Bank0	None		ON
3 R_ADDR[0]	INPUT	LVCMOS18	AA3		INBUF	Bank0	None		ON
4 R_ADDR[1]	INPUT	LVCMOS18	B4		INBUF	Bank0	None		ON
5 R_ADDR[2]	INPUT	LVCMOS18	U2		INBUF	Bank0	None		ON
6 R_ADDR[3]	INPUT	LVCMOS18	T4		INBUF	Bank0	None		ON
7 R_ADDR[4]	INPUT	LVCMOS18	W2		INBUF	Bank0	None		ON
8 R_ADDR[5]	INPUT	LVCMOS18	AA5		INBUF	Bank0	None		ON
9 R_DATA	OUTPUT	LVCMOS18			OUTBUF	Bank0	None		ON
10 R_DATA[0]	OUTPUT	LVCMOS18	V5		OUTBUF	Bank0	None		ON
11 R_DATA[1]	OUTPUT	LVCMOS18	P2		OUTBUF	Bank0	None		ON
12 R_DATA[2]	OUTPUT	LVCMOS18	M1		OUTBUF	Bank4	None		ON
13 R_DATA[3]	OUTPUT	LVCMOS18	M0		OUTBUF	Bank4	None		ON
14 R_DATA[4]	OUTPUT	LVCMOS18	M5		OUTBUF	Bank4	None		ON
15 R_DATA[5]	OUTPUT	LVCMOS18	U4		OUTBUF	Bank0	None		ON
16 R_DATA[6]	OUTPUT	LVCMOS18	AA4		OUTBUF	Bank0	None		ON
17 R_DATA[7]	OUTPUT	LVCMOS18	V1		OUTBUF	Bank0	None		ON
18 R_DATA[8]	OUTPUT	LVCMOS18	B2		OUTBUF	Bank0	None		ON
19 R_DATA[9]	OUTPUT	LVCMOS18	K2		OUTBUF	Bank4	None		ON
20 R_DATA[10]	OUTPUT	LVCMOS18	U1		OUTBUF	Bank0	None		ON
21 R_DATA[11]	OUTPUT	LVCMOS18	P4		OUTBUF	Bank0	None		ON
22 W_ADDR	INPUT	LVCMOS18			INBUF	Bank0	None		ON
23 W_ADDR[0]	INPUT	LVCMOS18	Y1		INBUF	Bank0	None		ON
24 W_ADDR[1]	INPUT	LVCMOS18	Y4		INBUF	Bank0	None		ON
25 W_ADDR[2]	INPUT	LVCMOS18	P1		INBUF	Bank0	None		ON
26 W_ADDR[3]	INPUT	LVCMOS18	T5		INBUF	Bank0	None		ON
27 W_ADDR[4]	INPUT	LVCMOS18	K1		INBUF	Bank4	None		ON

Notes: See the following documents for more information about the I/O standards supported by each attribute:

- [PDC Commands User Guide for SmartFusion2, IGLOO2, and RTG4](#)
- [PDC Commands User Guide for PolarFire FPGA](#)

2.1. Port Name [\(Ask a Question\)](#)

This is the port list of the design. The ports of the design are displayed in a structured manner according to group name/functions. Ports can be expanded or collapsed. The port list can be sorted or filtered, in a way similar to the Windows spreadsheet operations. For example, entering RESET in the match field in the filter returns a list of port names that have RESET in the port name.

2.2. Direction [\(Ask a Question\)](#)

Non-editable field that denotes Input, Output, or Inout.

2.3. I/O Standard [\(Ask a Question\)](#)

This field specifies the I/O standard the device supports. Different I/O types have different I/O standards. The pull-down list displays the valid I/O standards for that particular type of I/Os. The list of valid I/O standards is limited to what the I/O bank (to which the I/O belongs) can support.

2.4. Pin Number [\(Ask a Question\)](#)

This is the package pin number specific to the die and package of the device.

2.5. Locked [\(Ask a Question\)](#)

If checked, the current pin assignment cannot be changed during layout.

2.6. Macro Cell [\(Ask a Question\)](#)

This is a read-only field that identifies the name of the Macro cell associated with the Port.

2.7. Bank Name [\(Ask a Question\)](#)

This is a read-only field to identify the I/O bank the I/O pin is associated with. Depending on the device size, devices may have, six, or eight I/O Banks (Bank 0 through Bank 7) user I/O banks. Each pin is associated with an I/O bank. The I/O banks on the north side of the device support only HSIO. Each I/O bank has dedicated I/O supplies and grounds. Each I/O within a given bank shares the same VDDI power supply, and the same VREF reference voltage. Only compatible I/O standards can be assigned to a given I/O bank.

2.8. User I/O Lock Down [\(Ask a Question\)](#)

If checked, the pin is controlled by the Tamper macro IO_Disable signal. When Tamper IO_Disable is asserted, the selected I/O pin is disabled. Inputs are disabled and detected as a logic low by FPGA fabric. Outputs are tri-state with any configured pull-up or pull-down still honored.

Note: This is applicable for PolarFire and PolarFire SoC families only.

2.9. I/O State in Flash*Freeze Mode [\(Ask a Question\)](#)

By default, all I/Os become tri-stated when the device goes into Flash*Freeze mode. You can override this default behavior by setting one of the following two values:

- **LAST_VALUE**—When set to this value, it preserves the previous state of the I/O. This means the I/O remains in the same state in which it had functioned before the device went into Flash*Freeze mode.
- **LAST VALUE_WP**—When set to this value, it preserves the last value with weak pull-up.

Note: This I/O attribute is applicable for SmartFusion 2 and IGLOO 2 families only.

2.10. Clamp Diode [\(Ask a Question\)](#)

PolarFire devices have internal PCI clamp diodes for both HSIO and GPIO. PCI clamp diodes help reduce the voltage level at the input, and are mainly used when the voltage overshoot exceeds the maximum allowable limit. If signaling levels of the receiver are greater than the VDDIx of the bank, the clamp diode must be off to support hot-socketing insertion.

For GPIO, use this field to program the clamp diode to be ON or OFF.

For HSIO, the internal clamp diode is always ON by default.

2.11. Resistor Pull [\(Ask a Question\)](#)

Use this field to allow the inclusion of a weak resistor for either pull-up or pull-down of the input or output buffer. The available options are None, Up (pull-up), Down (pull-down), or Hold. The default value is Up.

Note: Not all I/O standards have a selectable resistor pull option.

2.12. I/O Available in Flash*Freeze Mode [\(Ask a Question\)](#)

Use this field to indicate if the I/O is available or unavailable in Flash*Freeze mode. The default value is **No** and the I/O is unavailable in Flash*Freeze mode.

Note: This I/O attribute is applicable for SmartFusion 2 and IGLOO 2 families only.

2.13. Use I/O Calibration from the Lane [\(Ask a Question\)](#)

The **Use I/O Calibration from the Lane** option supports the PolarFire and PolarFire SoC devices. This feature allows you to configure I/O to opt-out of recalibration. Use this feature either to delay or sequence calibration themselves or to account for VT impact on I/O performance. Default is OFF.

If you open an old design and you open the I/O Editor, you will not see this option. You must re-run compile to see the option.

Note: The **Use I/O Calibration from the Lane** option is not supported for ES and XT devices.

2.14. Schmitt Trigger [\(Ask a Question\)](#)

GPIO and HSIO can be configured as a Schmitt Trigger input. When configured as ON, it exhibits a hysteresis that helps to filter out the noise at the receiver and prevents double-glitching caused by noisy input edges. Default configuration is OFF (Schmitt Trigger disabled).

2.15. Vcm Input Range [\(Ask a Question\)](#)

Use this field to set the Vcm input range.

Direction: Input

Note: This field is valid for PolarFire and PolarFire SoC devices only.

2.16. On-Die Termination [\(Ask a Question\)](#)

On-Die Termination (ODT) is an option used to terminate input signals in PolarFire devices. Terminating input signals helps to maintain signal quality, save board space, and reduces external component costs. In SmartFusion 2, IGLOO 2, RTG4, and PolarFire FPGAs, ODT is available in receive mode and also in bidirectional mode when the I/O acts as an input. If ODT is not used or not available, the I/O standards may require external termination for better signal integrity.

ODT can be a pull-up, pull-down, differential, or Thévenin termination with both static and dynamic control available, and is set using either the Libero® SoC software I/O attribute editor or by using a PDC command.

In addition, ODT can be controlled dynamically for individual I/Os as well as for all I/Os in a lane simultaneously on a per-lane basis.

2.17. ODT Static [\(Ask a Question\)](#)

On-die termination (ODT) is the technology where the termination resistor for impedance matching in transmission lines is located inside a semiconductor chip instead of on a printed circuit board. Possible values are listed in the following table.

Table 2-1. ODT Static Values and Descriptions

Value	Description
on	Yes, the termination resistor for impedance matching is located inside the chip.
off	No, the termination resistor is on the printed circuit board.

2.18. ODT Dynamic [\(Ask a Question\)](#)

Note: This option is supported for RTG4 production devices only.

This option is used to opt in or out of the dynamic ODT set on a bank. Possible value are listed in the following table.

Table 2-2. ODT Dynamic Values and Descriptions

Value	Description
ODT_STATIC=On ODT_DYNAMIC=On	Illegal
ODT_STATIC=On ODT_DYNAMIC=Off	The ODT resistor is always turned on.
ODT_STATIC=Off ODT_DYNAMIC=Off	The ODT resistor is always turned off.
ODT_STATIC=Off ODT_DYNAMIC=On	The ODT resistor is on or off based on the ODT Dynamic bank setting.

The following I/O standards are supported:

- LVDS
- RSDS
- MINILVDS
- LVPECL
- HSTLI
- HSTLII
- SSTL15I
- SSTL15II
- SSTL18I
- SSTL18II
- HSTL18I
- HSTL18II
- LPDDR1
- LPDDR2

Note: There is a known issue in the Libero SoC I/O Editor and the pin report. A software limitation exists where a design cannot have different values for the P and N sides. Currently, both must have the same value. Libero SoC does program the P and N side correctly for programming. In I/O Editor or pin report, if RES_PULL is Up on both, it means the N side is programmed as Down or vice versa.

2.19. ODT Value [\(Ask a Question\)](#)

If the ODT option is turned on, the ODT Value (ohm) field can be set to any one of the values in the pull- down list. The ODT Value varies with different I/O standards.

2.20. ODT Imp (Ohm) [\(Ask a Question\)](#)

Port Configuration (PC) bits are static configuration bits set during programming to configure the I/O(s) as per your choice. See your device data sheet for a full range of possible values.

2.21. Low Power Exit [\(Ask a Question\)](#)

For single-ended I/Os, the Lower Power Exit value can be set from the drop-down list. The supported values for single-ended IOs are Off, Wake On Change, Wake On 0, Wake On 1. The default is Off.

The diff I/Os are marked as read-only fields and will be set to off.

2.22. Input Delay [\(Ask a Question\)](#)

Sets the Input Delay.

Input Delay applies to all I/O standards. The range of values supported varies depending on the device selected. The default value is OFF.

Note: This attribute will not appear in the I/O attributes and cannot be used in the PDC for some I/Os with dynamic delays, such as DDR I/Os.

2.23. Slew [\(Ask a Question\)](#)

The slew rate is the amount of rise or fall time an input signal takes to get from logic low to logic high or vice versa. It is commonly defined to be the propagation delay between 10% and 90% of the signal's voltage swing. The I/O Editor supports slew rate control in non-differential output mode. Turning the slew rate on results in faster slew rate, which improves the available timing margin. When slew rate is turned off, the device uses the maximum slew rate for the I/O standard to reduce the impact of simultaneous switching noise (SSN). By default, the slew control is OFF. Not all I/O standards support the slew rate control.

2.24. Pre-Emphasis [\(Ask a Question\)](#)

The pre-emphasis rate is the amount of rise or fall time an input signal takes to get from logic low to logic high or vice versa. It is commonly defined to be the propagation delay between 10% and 90% of the signal's voltage swing. The following table lists the possible values.

Table 2-3. Pre-emphasis Rate Values and Descriptions

Value	Description
NONE	Sets to none (default)
MIN	Sets to minimum
MEDIUM	Sets to medium
MAX	Sets to maximum

2.25. Output Drive [\(Ask a Question\)](#)

Use the Output Drive (mA) field to set the output drive strength. The output drive strength that can be set is different with different I/O standards and can vary from 1 mA to 20 mA. Select the drive strength value from the list of valid values in the pull-down list.

2.26. Impedance [\(Ask a Question\)](#)

Use the Impedance (Ohm) field in the I/O Editor to program the output impedance values. The Impedance value is different with different I/O standards and can vary from 22Ω to 240Ω. Click on the Impedance (Ohm) field to open a pull-down list containing valid values.

2.27. Output Load [\(Ask a Question\)](#)

The Output Load (pF) field indicates the output capacitance value based on the I/O standard. If necessary, you can double click on the respective I/O port to change the output capacitance value to improve timing definition and analysis. Output capacitance affects output propagation delay.

SmartTime, Timing-driven layout, and Backannotation automatically use the modified delay model for delay calculations.

2.28. Source Termination [\(Ask a Question\)](#)

The Source Termination (Ohm) field is the Near End termination for a differential output I/O. The default is OFF.

Direction: Output

2.29. Output Delay [\(Ask a Question\)](#)

Sets the Output Delay.

Output Delay applies to all I/O standards. The default value is OFF.

Direction: Output


Note: This attribute will not appear in the I/O attributes and cannot be used in the PDC for some I/Os with dynamic delays, such as DDR I/Os.

3. Pin View [\(Ask a Question\)](#)

The Pin View displays the I/O attributes of I/O attributes in a spreadsheet-like format. Each row corresponds to an I/O macro (port) in the design, sorted by pin number. The column headings specify the names of the I/O attributes in your design. The first few column headings are standard and common for all families. The remaining columns display family-specific attributes. Only attributes applicable to a specific device appear in the I/O Editor attributes. For some I/O attributes, you will choose from a drop-down menu; for others, you may enter a value and for the rest, the field is read-only and not editable.

The display in the columns can be sorted alphabetically, numerically or filtered. See the following figure.

Figure 3-1. Pin View



Notes: See the following documents for more information about the I/O standards supported by each attribute:

- [PDC Commands User Guide for SmartFusion2, IGLOO2, and RTG4](#)
- [PDC Commands User Guide for PolarFire FPGA](#)

3.1. Pin Number [\(Ask a Question\)](#)

This is the read-only package pin number specific to the die and package of the device.

3.2. Port Name [\(Ask a Question\)](#)

This is an editable field for the assignment of a port to that particular pin number. It contains a pull-down list of the assignable and available Ports for the pin. Select Unassigned to leave the pin unassigned.

3.3. Direction [\(Ask a Question\)](#)

Non-editable field that denotes Input, Output, or Inout.

3.4. Macro Cell [\(Ask a Question\)](#)

This is a read-only field that identifies the name of the macro cell associated with the port.

3.5. Bank Name [\(Ask a Question\)](#)

This is a read-only field to identify the I/O bank the I/O pin is associated with. Devices may have five, six, or eight user I/O banks (Bank 0 through Bank 7), depending on the device size. Each pin is associated with an I/O bank. The I/O banks on the north side of the device support only HSIO. Each I/O bank has dedicated I/O supplies and grounds. Each I/O within a given bank shares the same

VDDI power supply, and the same VREF reference voltage. Only compatible I/O standards can be assigned to a given I/O bank.

3.6. **Function** [\(Ask a Question\)](#)

The function name identifies the functions of the pin/port. This is the same as what is listed in the Public Pin Assignment Table (PPAT) for the selected device and package. For details, see the device data sheet of the die/package.

The function name may contain the following information:

- Type of I/O: GPIO or HSIO
- Special-purpose I/Os (for example, XCVR)
- The I/O Bank Number
- Positive/Negative Pad of differential I/Os
- VSS or Ground

3.7. **Locked** [\(Ask a Question\)](#)

If checked, the current pin assignment cannot be changed during layout.

3.8. **User Reserved** [\(Ask a Question\)](#)

For the I/O pin you want to reserve for use in another design, check the User Reserved checkbox to reserve it. When a pin is reserved, you cannot assign it to a port.

3.9. **Dedicated** [\(Ask a Question\)](#)

If checked, the pin is reserved for some special functionality, such as UJTAG, Power, XVCR Reference Clock, device reset, and clock functions.

3.10. **Vref** [\(Ask a Question\)](#)

Any GPIO and HSIO pad on the device can be configured to act as an external VREF to supply all inputs within a bank. Use this field to configure the I/O as VREF to other I/Os. When an I/O pad is configured as Vref (voltage referenced), all I/O buffer modes and terminations on that pad are disabled.

3.11. **User I/O Lock Down** [\(Ask a Question\)](#)

If checked, the pin is controlled by the Tamper macro IO_Disable signal. When Tamper IO_Disable is asserted, the selected I/O pin is disabled. Inputs are disabled and detected as a logic low by FPGA fabric. Outputs are tri-state with any configured pull-up or pull-down still honored.

Note: This is applicable for PolarFire and PolarFire SoC families only.

3.12. **I/O State in Flash*Freeze Mode** [\(Ask a Question\)](#)

By default, all I/Os become tri-stated when the device goes into Flash*Freeze mode. You can override this default behavior by setting one of the following two values:

- LAST_VALUE—When set to this value, it preserves the previous state of the I/O. This means the I/O remains in the same state in which it had functioned before the device went into Flash*Freeze mode.
- LAST VALUE_WP—When set to this value, it preserves the last value with weak pull-up.

Note: This I/O attribute is applicable for SmartFusion 2 and IGLOO 2 families only.

3.13. **Clamp Diode** [\(Ask a Question\)](#)

PolarFire devices have internal PCI clamp diodes for both HSIO and GPIO. PCI clamp diodes help reduce the voltage level at the input, and are mainly used when the voltage overshoot exceeds the maximum allowable limit. If signaling levels of the receiver are greater than the VDDI_x of the bank, the clamp diode must be off to support hot-socketing insertion.

For GPIO, use this field to program the clamp diode to be ON or OFF.

For HSIO, the internal clamp diode is always on by default.

3.14. Resistor Pull [\(Ask a Question\)](#)

Use this field to allow inclusion of a weak resistor for either pull-up or pull-down of the input or output buffer. The available options are None, Up (pull-up), Down (pull-down), or Hold. The default value is None.

Note: Not all I/O standards have a selectable resistor pull option.

3.15. I/O Available in Flash*Freeze Mode [\(Ask a Question\)](#)

Use this field to indicate if the I/O is available or unavailable in Flash*Freeze mode. The default value is **No** and the I/O is unavailable in Flash*Freeze mode.

Note: This I/O attribute is applicable for SmartFusion 2 and IGLOO 2 families only.

3.16. Schmitt Trigger [\(Ask a Question\)](#)

GPIO and HSIO can be configured as a Schmitt Trigger input. When enabled as such (YES), it exhibits a hysteresis that helps to filter out the noise at the receiver and prevents double-glitching caused by noisy input edges. Default value is OFF.

3.17. Vcm Input Range [\(Ask a Question\)](#)

Values for all I/O standards are MID and LOW. The default is MID.

Note: This field is valid for PolarFire and PolarFire SoC devices only.

3.18. On-Die Termination [\(Ask a Question\)](#)

On-Die Termination (ODT) is an option used to terminate input signals in PolarFire devices. Terminating input signals helps to maintain signal quality, save board space, and reduces external component costs. In PolarFire FPGAs, ODT is available in receive mode and also in bidirectional mode when the I/O acts as an input. If ODT is not used or not available, the I/O standards may require external termination for better signal integrity.

ODT can be a pull-up, pull-down, differential, or Thévenin termination with both static and dynamic control available, and is set using either the Libero SoC software I/O attribute editor or by using a PDC command.

In addition, ODT can be controlled dynamically for individual I/Os as well as for all I/Os in a lane simultaneously on a per-lane basis.

3.19. ODT Static [\(Ask a Question\)](#)

On-die termination (ODT) is the technology where the termination resistor for impedance matching in transmission lines is located inside a semiconductor chip instead of on a printed circuit board. The following table lists the possible values.

Table 3-1. ODT Static Values and Descriptions

Value	Description
on	Yes, the termination resistor for impedance matching is located inside the chip.
off	No, the termination resistor is on the printed circuit board.

3.20. ODT Dynamic [\(Ask a Question\)](#)

Note: This option is supported for RTG4 production devices only.

This option is used to opt in or out of the dynamic odt set on a bank. Possible value are listed in the following table.

Table 3-2. ODT Dynamic Values and Descriptions

Value	Description
ODT_STATIC=On ODT_DYNAMIC=On	Illegal
ODT_STATIC=On ODT_DYNAMIC=Off	The ODT resistor is always turned on.
ODT_STATIC=Off ODT_DYNAMIC=Off	The ODT resistor is always turned off.
ODT_STATIC=Off ODT_DYNAMIC=On	The ODT resistor is On or Off based on the ODT Dynamic bank setting.

The following I/O standards are supported:

- LVDS
- RSDS
- MINILVDS
- LVPECL
- HSTLI
- HSTLII
- SSTL15I
- SSTL15II
- SSTL18I
- SSTL18II
- HSTL18I
- HSTL18II
- LPDDR1
- LPDDR2

3.21. ODT Value [\(Ask a Question\)](#)

If ODT option is turned on, the ODT Value (Ohm) field can be set to any one of the values in the pull-down list. The ODT Value varies with different I/O standards.

Values vary depending on the I/O standard.

3.22. ODT Imp (Ohm) [\(Ask a Question\)](#)

On-die termination (ODT) is the technology where the termination resistor for impedance matching in transmission lines is located inside a semiconductor chip instead of on a printed circuit board.

Port Configuration (PC) bits are static configuration bits set during programming to configure the I/O(s) as per your choice. See your device datasheet for a full range of possible values.

3.23. Low Power Exit [\(Ask a Question\)](#)

For single-ended I/Os, the Lower Power Exit value can be set from the drop-down list. The supported values for single-ended IOs are Off, Wake On Change, Wake On 0, and Wake On 1. The default is Off.

The differential I/Os are marked as read-only fields and will be set to off.

3.24. Input Delay [\(Ask a Question\)](#)

Sets the Input Delay.

Input Delay applies to all I/O standards. The range of values supported varies depending on the device selected. The default value is OFF.

Note: This attribute will not appear in the I/O attributes and cannot be used in the PDC for some I/Os with dynamic delays, such as DDR I/Os.

3.25. Slew [\(Ask a Question\)](#)

The slew rate is the amount of rise or fall time an input signal takes to get from logic low to logic high or vice versa. It is commonly defined to be the propagation delay between 10% and 90% of the signal's voltage swing. The I/O Editor supports slew rate control in non-differential output mode.

Turning the slew rate on (either by setting it to ON in the I/O Editor or in a PDC file) results in a slew rate limited for the I/O standard in the device. When the value for SLEW in the I/O Editor or PDC command is (chosen) OFF, the device uses the maximum slew rate for the I/O standard to reduce the impact of simultaneous switching noise (SSN). Not all I/O standards support the slew rate control.

Note: Slew rate control is not available in PolarFire HSIO buffers. However, these buffers have built-in PVT- compensated slew rate controllers for optimized signal integrity.

3.26. Pre-Emphasis [\(Ask a Question\)](#)

The pre-emphasis rate is the amount of rise or fall time an input signal takes to get from logic low to logic high or vice versa. It is commonly defined to be the propagation delay between 10% and 90% of the signal's voltage swing. Possible values are shown in the following table.

Table 3-3. Pre-emphasis Values and Descriptions

Value	Description
NONE	Sets to none (default)
MIN	Sets to minimum
MEDIUM	Sets to medium
MAX	Sets to maximum

3.27. Output Drive [\(Ask a Question\)](#)

Use the Output Drive (mA) field to set the output drive strength. The output drive strength that can be set is different with different I/O standards and can vary from 1 to 20 mA. Select the drive strength value from the list of valid values in the pull-down list.

3.28. Impedance [\(Ask a Question\)](#)

Use the Impedance (Ohm) field in the I/O Editor to program the output impedance values. Impedance values are different for different I/O standards, and can vary from 22Ω to 240Ω. Use the pull-down list to select the desired Ohm value.

3.29. Output Load [\(Ask a Question\)](#)

The Output Load (pF) field indicates the output capacitance value based on the I/O standard. If necessary, you can double click on the respective I/O port to change the output capacitance value to improve timing definition and analysis. Output capacitance affects output propagation delay.

SmartTime, Timing-driven layout, and Backannotation automatically use the modified delay model for delay calculations.

3.30. Source Termination [\(Ask a Question\)](#)

The Source Termination (Ohm) field is the Near End termination for a differential output I/O. The default is OFF.

Direction: Output

3.31. Output Delay [\(Ask a Question\)](#)

Sets the Output Delay.

Output Delay applies to all I/O standards. The range of values supported varies depending on the device selected. The default value is OFF. The default value is OFF.


Direction: Output

Note: This attribute will not appear in the I/O attributes and cannot be used in the PDC for some I/Os with dynamic delays, such as DDR I/Os.

4. Package View [\(Ask a Question\)](#)

The Package View displays the Package pin views of the particular die/package of the PolarFire device. The color for the display of the pins are determined by the settings in Display Options. The following figure shows the regular pins in green, special pins in blue, reserved pins in red, and unconnected pins in grey.

Figure 4-1. Package View



5. Interface—Specific I/Os and Views [\(Ask a Question\)](#)

The PolarFire architecture is designed and optimized to support Memory interface, IOD interface, and Transceiver interface. The I/O Editor for PolarFire provides three special views specifically for I/O assignments of these interfaces.

For optimal Quality of Result (QOR) and timing performance, the architecture of the PolarFire silicon requires the Memory Interface, IOD Interface and Transceiver Interface be placed in specific and pre-defined locations of the chip. Assignment of these interfaces are checked against PolarFire DRC rules and illegal assignments are flagged.


The I/O Editor is a Graphical User Interface (GUI) tool designed to make Interface I/O pin assignments graphically and user-friendly, as an alternative to writing PDC commands. When the pin assignment is committed and saved in I/O Editor, a PDC file is created. This PDC file can then be passed to the Place and Route tool as a Physical Design Constraint.

5.1. Interface—Specific I/O Views [\(Ask a Question\)](#)

In addition to the Pin view, Port view and Package view, the I/O Editor provides three views specific to PolarFire-supported interfaces I/Os:

- Memory View—for I/O pin assignments of Memory interfaces such as DDR3/4, LPDDR3, and QDR.
- XCVR View—Presents a physical view of the Transceiver connectivity, including Transceiver lanes, Reference Clock (REFCLK), and Transmit PLL lines.
- IOD Lane Controller View—Presents the I/O Digital block view, used for non-memory interfaces using the FPGA I/Os.

Figure 5-1. I/O Editor—XCVR View



6. Memory Interface View [\(Ask a Question\)](#)

The Memory Interface view presents a spreadsheet-like view of the I/Os available in the PolarFire silicon for different Memory interface types.

6.1. Memory Type [\(Ask a Question\)](#)

The supported Memory Interface types include:

- DDR3
- DDR4
- LPDDR3
- QDRII+

Use the pull-down menu to select the type of Memory Interface used in the design. Only the specific type of memory used in the design are displayed in the pull-down list.

The Ports view also displays the memory width and data rate of the DDR instance in the design (if it exists in the design) in the top left row under the Port Name column, as shown in the following figure.

Figure 6-1. Memory Interface Type Menu

Port Function	Port Name	Pin Number	Function	Max Memory Width	Max Data Rate	Bank Name
1 NORTH_NE	PF_DDR3_SS_0[width=16, rate=1333.33]	146	Assigned	72	1336	---
291 NORTH_NW	Assigned	16	1336	---		
364 SOUTH_SE	Assigned	40	800	---		
458 SOUTH_SW	Unassigned	72	800	---		
599 WEST_NW	Unassigned	64	800	---		

6.2. Edge_Anchors for Memory Placement [\(Ask a Question\)](#)

The PolarFire silicon architecture requires that the Memory interface be placed in specific and pre-defined locations of the chip to achieve optimal QOR and timing performance. These specific location are called Edge_Anchors and are used to identify the specific location in the PolarFire chip for optimal Memory Interface I/O placement. See the [PolarFire Family Memory Controller User Guide](#) for a mapping of DDR memory interface types to Edge_Anchor locations. The Edge_Anchors are as follows:

- NORTH_NE
- NORTH_NW
- SOUTH_SE
- SOUTH_SW
- WEST_NW
- WEST_SW

The ports for each Edge_Anchor is represented by a different color for easy identification. The list of possible Edge_Anchors is context-sensitive to the Memory Interface type and represents the legal and optimal locations for the specific Memory interface type. The list of Edge_Anchors for DDR4, for

example, is different from the list for DD2/DDR3. DDR4 has fewer locations (Edge_Anchors) for I/O placement than DDR2/DD3.

6.3. Memory Interface View Columns [\(Ask a Question\)](#)

The Memory Interface view detects the type of Memory Interface in the design and presents the ports in the Ports View. The Memory Interface view displays the following I/O information in the view. Each of the column can be sorted (ascending/descending order) or filtered:

- Port Function—Formal port name of the Memory Interface. The ports specific to the memory interface type are loaded into the Port View.
- Port Name—Port name of the Memory Interface instance in the design.
- Pin Number—Package pin number assigned to the port of the Memory Interface.
- Function—More descriptive function name of the Port, which identifies the type of I/O (for example, HSIO for High-speed I/Os or GPIO (General-purpose Input/Output).
- Max Memory Width—Maximum memory width of the DDR. This is a fixed read-only value specific to the Edge_Anchor and is different with different Edge_Anchors.
- Max Data Rate—Maximum data rate in Mbps. This is a fixed read-only value specific to the Edge_Anchor and is different with different Edge_Anchors.

Notes: When making DDR placement, see the memory width and data rate of the DDR Memory used in the design (as displayed in the Ports View). Make sure that the Edge_Anchor location, where you want to place the DDR memory, can accommodate the DDR memory in terms of the memory width and the data rate. This will avoid invalid placement.

- Bank Name—the I/O bank name of the port
- High-speed I/O Clocks—specifies the number of High Speed I/O clocks

The Pin Number and Function are the same as what are listed in the PPAT for the selected device and package. The PPAT for each PolarFire package are provided in the PolarFire_<package> Pinouts file on the [PolarFire Documentation](#) web page.

The following figure shows memory interface view.

Figure 6-2. Memory Interface View

Port Function	Port Name	Pin Number	Function	Max Memory Width	Max Data Rate	Bank Name
NORTH_NE	PF_DDR3_SS_0[width=16, rate=1333.33]			72	1336	...
A0	A_0[0]	AL27	HSIO72NB1	72	1336	Bank1
A1	A_0[1]	AL26	B1/CCC_NE_CLK	72	1336	Bank1
A2	A_0[2]	AM27	HSIO73NB1	72	1336	Bank1
A3	A_0[3]	AN27	B1/CCC_NE_PL	72	1336	Bank1
A4	A_0[4]	AN26	HSIO76NB1	72	1336	Bank1
A5	A_0[5]	AP25	HSIO76PB1	72	1336	Bank1
A6	A_0[6]	AL25	HSIO77NB1	72	1336	Bank1
A7	A_0[7]	AK25	HSIO77PB1	72	1336	Bank1
A8	A_0[8]	AJ23	HSIO79NB1	72	1336	Bank1
A9	A_0[9]	AM23	B1/CCC_NE_PL	72	1336	Bank1
A10	A_0[10]	AJ25	HSIO81NB1/DQ5	72	1336	Bank1
A11	A_0[11]	AJ24	/DQ5/CCC_NE_I	72	1336	Bank1
A12	A_0[12]	AL22	HSIO82NB1	72	1336	Bank1
A13	A_0[13]	AK23	HSIO82PB1	72	1336	Bank1
A14	A_0[14]	AL24	HSIO83NB1	72	1336	Bank1
A15	A_0[15]	AL23	HSIO83PB1	72	1336	Bank1
BA0	BA_0[0]	AE25	HSIO84PB1	72	1336	Bank1
BA1	BA_0[1]	AD23	HSIO85NB1	72	1336	Bank1
BA2	BA_0[2]	AD25	HSIO84NB1	72	1336	Bank1
CAS_N	CAS_N_0	AF25	HSIO86NB1	72	1336	Bank1
CK0_0	CK0_0	AP26	/DQ5/CCC_NE_I	72	1336	Bank1
CK0_N	CK0_N_0	AP27	HSIO75NB1/DQ5	72	1336	Bank1
CK1	Unassigned	AM25	E_CLKIN_N_10/C	72	1336	Bank1
CK1_N	Unassigned	AM26	HSIO74NB1	72	1336	Bank1
CKE0	CKE_0	AF22	HSIO87PB1/DQ5	72	1336	Bank1
CKE1	Unassigned	AD24	HSIO89PB1	72	1336	Bank1
CS0_N	CS_N_0	AE22	HSIO87NB1/DQ5	72	1336	Bank1
CS1_N	Unassigned	AH24	CCC_NE_CLKIN_N	72	1336	Bank1
DM0	DM[0]	AN23	HSIO95NB1	72	1336	Bank1
DM1	DM[1]	AL20	HSIO101PB1	72	1336	Bank1
DM2	Unassigned	AK18	HSIO107NB7	72	1336	Bank7
DM3	Unassigned	AL14	HSIO113NB7	72	1336	Bank7
DM4	Unassigned	AD19	HSIO119NB7	72	1336	Bank7

6.4. Making I/O Assignments [\(Ask a Question\)](#)


To make I/O assignment for the Memory Interface instance in the design:

1. Select the Memory Interface type from the drop-down menu.
2. From the Ports tab in the Design Tree View, drag the Memory Interface instance and let the mouse hover over one of the Edge_Anchor locations available for the Memory Interface type. A tooltip reports whether it is a legal or illegal location for the Interface instance.
3. Drop the Interface instance into a legal Edge_Anchor location.

Note: DRC rules are enforced. Drag-and-drop I/O placement that violates the DRC rules are reported in the Log window. For Memory Interface, the DRC checks the Data Width and the Data Rate compliance*. If the specific location cannot accommodate the Data Width or the Data Rate of the Memory interface, no I/O assignment is made. An error is reported in the Log Window with a message that explains why the assignment is not accepted. In the following figure, the DRC error message reports that the ddr3 instance requires 64 ports, but the SOUTH_SE location can accommodate only 58 pins.

Note: *Data Rate compliance will be enforced in a later release.

Figure 6-3. DRC Checks in Log Window



4. Check that no DRC error messages are reported in the Log window and the I/O assignments are accepted (see the following figure). The Lock icon in the Ports tab indicates that the I/O assignment is accepted and locked.

Figure 6-4. Memory Interface Assignments Accepted

Port View

Pin View

XCVR View

Memory View [active]

IOD View

Package View

Floorplanner View

Netlist Viewer - Hier

Netlist Viewer - Flat

Ports

I/O Ports

DDR4

DDR3

PF_DDR3_SS_0(width=16, rate=1333)

Lane2-ADDR/CMD

Lane1-ADDR/CMD

Lane5-ADDR/CMD

CK0_0

CK0_N_0

Lane-DQ[7:0]

Lane-DQ[15:8]

SHIELD0_0

SHIELD1_0

Dedicated Ports

Memory Type: DDR3

	Port Function	Port Name	Pin Number	Function	Max Memory Width	Max Data Rate	Bank Name
13	A11	A_0[11]	AJ34	/DOS/CCC_NE_I	72	1336	Bank1
14	A12	A_0[12]	AL22	HSIO82NB1	72	1336	Bank1
15	A13	A_0[13]	AK23	HSIO82PB1	72	1336	Bank1
16	A14	A_0[14]	AL24	HSIO83NB1	72	1336	Bank1
17	A15	A_0[15]	AL23	HSIO83PB1	72	1336	Bank1
18	BA0	BA_0[0]	AE25	HSIO84PB1	72	1336	Bank1
19	BA1	BA_0[1]	AD23	HSIO85NB1	72	1336	Bank1
20	BA2	BA_0[2]	AD25	HSIO84NB1	72	1336	Bank1
21	CAS_N	CAS_N_0	AF25	HSIO86NB1	72	1336	Bank1
22	CK0	CK0_0	AP26	/DOS/CCC_NE_I	72	1336	Bank1
23	CK0_N	CK0_N_0	AP27	HSIO73NB1/DQS	72	1336	Bank1
24	CK1	Unassigned	AM25	E_CLKIN_N_10/C	72	1336	Bank1
25	CK1_N	Unassigned	AM26	HSIO74NB1	72	1336	Bank1
26	CKE0	CKE_0	AF22	HSIO87PB1/DQS	72	1336	Bank1
27	CKE1	Unassigned	AD24	HSIO89PB1	72	1336	Bank1
28	CS0_N	CS_N_0	AE22	HSIO87NB1/DQS	72	1336	Bank1
29	CS1_N	Unassigned	AH24	_CC_NE_CLKIN_N	72	1336	Bank1
30	DM0	DM[0]	AN23	HSIO95NB1	72	1336	Bank1
31	DM1	DM[1]	AL20	HSIO101PB1	72	1336	Bank1
32	DM2	Unassigned	AK18	HSIO107NB7	72	1336	Bank7
33	DM3	Unassigned	AL14	HSIO113NB7	72	1336	Bank7
34	DM4	Unassigned	AD19	HSIO119NB7	72	1336	Bank7
35	DM5	Unassigned	AL10	HSIO125NB7	72	1336	Bank7
36	DM6	Unassigned	AE15	HSIO131NB7	72	1336	Bank7
37	DM7	DQ[25]	AH11	HSIO137NB7	72	1336	Bank7
38	DM8	DQ[1]	AK42	HSIO143NB0	72	1336	Bank0
39	DQ0	DQ_0[0]	AN22	HSIO90NB1	72	1336	Bank1
40	DQ1	DQ_0[1]	AN21	HSIO90PB1	72	1336	Bank1
41	DQ2	DQ_0[2]	AM24	HSIO91NB1	72	1336	Bank1
42	DQ3	DQ_0[3]	AN24	HSIO91PB1	72	1336	Bank1
43	DQ4	DQ_0[4]	AP21	HSIO92NB1	72	1336	Bank1
44	DQ5	DQ_0[5]	AP20	HSIO92PB1	72	1336	Bank1
45	DQ6	DQ_0[6]	AP19	HSIO94NB1	72	1336	Bank1
46	DQ7	DQ_0[7]	AN19	HSIO94PB1	72	1336	Bank1
47	DQ8	DQ_0[8]	AA12	HSIO95NB1	72	1336	Bank1
48	DQ9	DQ_0[9]	AA11	HSIO95PB1	72	1336	Bank1
49	DQ10	DQ_0[10]	AA10	HSIO96NB1	72	1336	Bank1
50	DQ11	DQ_0[11]	AA09	HSIO96PB1	72	1336	Bank1
51	DQ12	DQ_0[12]	AA08	HSIO97NB1	72	1336	Bank1
52	DQ13	DQ_0[13]	AA07	HSIO97PB1	72	1336	Bank1
53	DQ14	DQ_0[14]	AA06	HSIO98NB1	72	1336	Bank1
54	DQ15	DQ_0[15]	AA05	HSIO98PB1	72	1336	Bank1
55	DQ16	DQ_0[16]	AA04	HSIO99NB1	72	1336	Bank1
56	DQ17	DQ_0[17]	AA03	HSIO99PB1	72	1336	Bank1
57	DQ18	DQ_0[18]	AA02	HSIO100NB1	72	1336	Bank1
58	DQ19	DQ_0[19]	AA01	HSIO100PB1	72	1336	Bank1
59	DQ20	DQ_0[20]	AA00	HSIO101NB1	72	1336	Bank1
60	DQ21	DQ_0[21]	AA00	HSIO101PB1	72	1336	Bank1
61	DQ22	DQ_0[22]	AA00	HSIO102NB1	72	1336	Bank1
62	DQ23	DQ_0[23]	AA00	HSIO102PB1	72	1336	Bank1
63	DQ24	DQ_0[24]	AA00	HSIO103NB1	72	1336	Bank1
64	DQ25	DQ_0[25]	AA00	HSIO103PB1	72	1336	Bank1
65	DQ26	DQ_0[26]	AA00	HSIO104NB1	72	1336	Bank1
66	DQ27	DQ_0[27]	AA00	HSIO104PB1	72	1336	Bank1
67	DQ28	DQ_0[28]	AA00	HSIO105NB1	72	1336	Bank1
68	DQ29	DQ_0[29]	AA00	HSIO105PB1	72	1336	Bank1
69	DQ30	DQ_0[30]	AA00	HSIO106NB1	72	1336	Bank1
70	DQ31	DQ_0[31]	AA00	HSIO106PB1	72	1336	Bank1
71	DQ32	DQ_0[32]	AA00	HSIO107NB1	72	1336	Bank1
72	DQ33	DQ_0[33]	AA00	HSIO107PB1	72	1336	Bank1
73	DQ34	DQ_0[34]	AA00	HSIO108NB1	72	1336	Bank1
74	DQ35	DQ_0[35]	AA00	HSIO108PB1	72	1336	Bank1
75	DQ36	DQ_0[36]	AA00	HSIO109NB1	72	1336	Bank1
76	DQ37	DQ_0[37]	AA00	HSIO109PB1	72	1336	Bank1
77	DQ38	DQ_0[38]	AA00	HSIO110NB1	72	1336	Bank1
78	DQ39	DQ_0[39]	AA00	HSIO110PB1	72	1336	Bank1
79	DQ40	DQ_0[40]	AA00	HSIO111NB1	72	1336	Bank1
80	DQ41	DQ_0[41]	AA00	HSIO111PB1	72	1336	Bank1
81	DQ42	DQ_0[42]	AA00	HSIO112NB1	72	1336	Bank1
82	DQ43	DQ_0[43]	AA00	HSIO112PB1	72	1336	Bank1
83	DQ44	DQ_0[44]	AA00	HSIO113NB1	72	1336	Bank1
84	DQ45	DQ_0[45]	AA00	HSIO113PB1	72	1336	Bank1
85	DQ46	DQ_0[46]	AA00	HSIO114NB1	72	1336	Bank1
86	DQ47	DQ_0[47]	AA00	HSIO114PB1	72	1336	Bank1
87	DQ48	DQ_0[48]	AA00	HSIO115NB1	72	1336	Bank1
88	DQ49	DQ_0[49]	AA00	HSIO115PB1	72	1336	Bank1
89	DQ50	DQ_0[50]	AA00	HSIO116NB1	72	1336	Bank1
90	DQ51	DQ_0[51]	AA00	HSIO116PB1	72	1336	Bank1
91	DQ52	DQ_0[52]	AA00	HSIO117NB1	72	1336	Bank1
92	DQ53	DQ_0[53]	AA00	HSIO117PB1	72	1336	Bank1
93	DQ54	DQ_0[54]	AA00	HSIO118NB1	72	1336	Bank1
94	DQ55	DQ_0[55]	AA00	HSIO118PB1	72	1336	Bank1
95	DQ56	DQ_0[56]	AA00	HSIO119NB1	72	1336	Bank1
96	DQ57	DQ_0[57]	AA00	HSIO119PB1	72	1336	Bank1
97	DQ58	DQ_0[58]	AA00	HSIO120NB1	72	1336	Bank1
98	DQ59	DQ_0[59]	AA00	HSIO120PB1	72	1336	Bank1
99	DQ60	DQ_0[60]	AA00	HSIO121NB1	72	1336	Bank1
100	DQ61	DQ_0[61]	AA00	HSIO121PB1	72	1336	Bank1
101	DQ62	DQ_0[62]	AA00	HSIO122NB1	72	1336	Bank1
102	DQ63	DQ_0[63]	AA00	HSIO122PB1	72	1336	Bank1
103	DQ64	DQ_0[64]	AA00	HSIO123NB1	72	1336	Bank1
104	DQ65	DQ_0[65]	AA00	HSIO123PB1	72	1336	Bank1
105	DQ66	DQ_0[66]	AA00	HSIO124NB1	72	1336	Bank1
106	DQ67	DQ_0[67]	AA00	HSIO124PB1	72	1336	Bank1
107	DQ68	DQ_0[68]	AA00	HSIO125NB1	72	1336	Bank1
108	DQ69	DQ_0[69]	AA00	HSIO125PB1	72	1336	Bank1
109	DQ70	DQ_0[70]	AA00	HSIO126NB1	72	1336	Bank1
110	DQ71	DQ_0[71]	AA00	HSIO126PB1	72	1336	Bank1
111	DQ72	DQ_0[72]	AA00	HSIO127NB1	72	1336	Bank1
112	DQ73	DQ_0[73]	AA00	HSIO127PB1	72	1336	Bank1
113	DQ74	DQ_0[74]	AA00	HSIO128NB1	72	1336	Bank1
114	DQ75	DQ_0[75]	AA00	HSIO128PB1	72	1336	Bank1
115	DQ76	DQ_0[76]	AA00	HSIO129NB1	72	1336	Bank1
116	DQ77	DQ_0[77]	AA00	HSIO129PB1	72	1336	Bank1
117	DQ78	DQ_0[78]	AA00	HSIO130NB1	72	1336	Bank1
118	DQ79	DQ_0[79]	AA00	HSIO130PB1	72	1336	Bank1
119	DQ80	DQ_0[80]	AA00	HSIO131NB1	72	1336	Bank1
120	DQ81	DQ_0[81]	AA00	HSIO131PB1	72	1336	Bank1
121	DQ82	DQ_0[82]	AA00	HSIO132NB1	72	1336	Bank1
122	DQ83	DQ_0[83]	AA00	HSIO132PB1	72	1336	Bank1
123	DQ84	DQ_0[84]	AA00	HSIO133NB1	72	1336	Bank1
124	DQ85	DQ_0[85]	AA00	HSIO133PB1	72	1336	Bank1
125	DQ86	DQ_0[86]	AA00	HSIO134NB1	72	1336	Bank1
126	DQ87	DQ_0[87]	AA00	HSIO134PB1	72	1336	Bank1
127	DQ88	DQ_0[88]	AA00	HSIO135NB1	72	1336	Bank1
128	DQ89	DQ_0[89]	AA00	HSIO135PB1	72	1336	Bank1
129	DQ90	DQ_0[90]	AA00	HSIO136NB1	72	1336	Bank1
130	DQ91	DQ_0[91]	AA00	HSIO136PB1	72	1336	Bank1
131	DQ92	DQ_0[92]	AA00	HSIO137NB1	72	1336	Bank1
132	DQ93	DQ_0[93]	AA00	HSIO137PB1	72	1336	Bank1
133	DQ94	DQ_0[94]	AA00	HSIO138NB1	72	1336	Bank1
134	DQ95	DQ_0[95]	AA00	HSIO138PB1	72	1336	Bank1
135	DQ96	DQ_0[96]	AA00	HSIO139NB1	72	1336	Bank1
136	DQ97	DQ_0[97]	AA00	HSIO139PB1	72	1336	Bank1
137	DQ98	DQ_0[98]	AA00	HSIO140NB1	72	1336	Bank1
138	DQ99	DQ_0[99]	AA00	HSIO140PB1	72	1336	Bank1
139	DQ100	DQ_0[100]	AA00	HSIO141NB1	72	1336	Bank1
140	DQ101	DQ_0[101]	AA00	HSIO141PB1	72	1336	Bank1
141	DQ102	DQ_0[102]	AA00	HSIO142NB1	72	1336	Bank1
142	DQ103	DQ_0[103]	AA00	HSIO142PB1	72	1336	Bank1
143	DQ104	DQ_0[104]	AA00	HSIO143NB1	72	1336	Bank1
144	DQ105	DQ_0[105]	AA00	HSIO143PB1	72	1336	Bank1
145	DQ106	DQ_0[106]	AA00	HSIO144NB1	72	1336	Bank1
146	DQ107	DQ_0[107]	AA00	HSIO144PB1	72	1336	Bank1
147	DQ108	DQ_0[108]	AA00	HSIO145NB1	72	1336	Bank1
148	DQ109	DQ_0[109]	AA00	HSIO145PB1	72	1336	Bank1
149	DQ110	DQ_0[110]	AA00	HSIO146NB1	72	1336	Bank1
150	DQ111	DQ_0[111]	AA00	HSIO146PB1	72	1336	Bank1
151	DQ112	DQ_0[112]	AA00	HSIO147NB1	72	1336	Bank1
152	DQ113	DQ_0[113]	AA00	HSIO147PB1	72	1336	Bank1
153	DQ114	DQ_0[114]	AA00	HSIO148NB1	72	1336	Bank1
154	DQ115	DQ_0[115]	AA00	HSIO148PB1	72	1336	Bank1
155	DQ116	DQ_0[116]	AA00	HSIO149NB1	72	1336	Bank1
156	DQ117	DQ_0[117]	AA00	HSIO149PB1	72	1336	Bank1
157	DQ118	DQ_0[118]	AA00	HSIO150NB1	72	1336	Bank1
158	DQ119	DQ_0[119]	AA00	HSIO150PB1	72	1336	Bank1
159	DQ120	DQ_0[120]	AA00	HSIO151NB1	72	1336	Bank1
160	DQ121	DQ_0[121]	AA00	HSIO151PB1	72	1336	Bank1
161	DQ122	DQ_0[122]	AA00	HSIO152NB1	72	1336	Bank1
162	DQ123	DQ_0[123]	AA00	HSIO152PB1	72	1336	Bank1
163	DQ124	DQ_0[124]	AA00	HSIO153NB1	72	1336	Bank1
164	DQ125	DQ_0[125]	AA00	HSIO153PB1	72	1336	Bank1
165	DQ126	DQ_0[126]	AA00	HSIO154NB1	72	1336	Bank1
166	DQ127	DQ_0[127]	AA00	HSIO154PB1	72	1336	Bank1
167	DQ128	DQ_0[128]	AA00	HSIO155NB1	72	1336	Bank1
168	DQ129	DQ_0[129]	AA00	HSIO155PB1	72	1336	Bank1
169	DQ130	DQ_0[130]	AA00	HSIO156NB1	72	1336	Bank1
170	DQ131	DQ_0[131]	AA00	HSIO156PB1	72	1336	Bank1
171	DQ132	DQ_0[132]	AA00	HSIO157NB1	72	1336	Bank1
172	DQ133	DQ_0[133]	AA00	HSIO157PB1	72	1336	Bank1
173	DQ134	DQ_0[134]	AA00	HSIO158NB1	72	1336	Bank1
174	DQ135	DQ_0[135]	AA00	HSIO158PB1	72	1336	Bank1
175	DQ136	DQ_0[136]	AA00	HSIO159NB1	72	1336	Bank1
176	DQ137	DQ_0[137]	AA00	HSIO159PB1	72	1336	Bank1
177	DQ138	DQ_0[138]	AA00	HSIO16			

6.5. IO_PDC File [\(Ask a Question\)](#)

When the I/O assignment is committed and saved in the I/O Editor, the assignment is saved in a PDC file in the <project_folder/constraints/io/user.pdc> file. The PDC file contains set_io commands on each of the DDR Memory Interface I/O.

The following figure shows PDC file generation after Memory interface I/O assignment in the I/O Editor.

Figure 6-5. PDC File Generation after Memory Interface I/O Assignment in I/O Editor

```
set_io -port_name {DQ[24]} \
  -pin_name AG11 \
  -fixed true \
  -ODT_VALUE 60 \
  -DIRECTION INOUT

set_io -port_name {DQ[25]} \
  -pin_name AH11 \
  -fixed true \
  -DIRECTION INOUT

set_io -port_name {DQ[26]} \
  -pin_name AG12 \
  -fixed true \
  -DIRECTION INOUT

set_io -port_name {DQ[27]} \
  -pin_name AH12 \
  -fixed true \
  -DIRECTION INOUT

set_io -port_name {DQ[28]} \
  -pin_name AJ10 \
  -fixed true \
  -DIRECTION INOUT

set_io -port_name {DQ[29]} \
  -pin_name AJ11 \
  -fixed true \
  -DIRECTION INOUT
```

6.6. Removing I/O Assignments [\(Ask a Question\)](#)

To remove a DDR Memory Interface I/O assignment:

1. Select the Port tab in the Design Tree view.
2. Right click the Memory Interface in the Design Tree view.
3. Select Unplace <memory_interface_name> .

See the following figure.

Figure 6-6. Removing Memory Interface I/O Assignment

Memory Type: DDR3

Port Function	Port Name	Pin Number	Function	Max Memory Width	Max Data Rate	Bank Name
NORTH1_NE	PF_DDR3_SS_0[width=16, rate=1333.33]			72	1336	
A0	A_0[0]	AL27	HSIO72NB1	72	1336	Bank1
A1	A_0[1]	AL26	B1/CCC_NE_CLK	72	1336	Bank1
A2	A_0[2]	AM27	HSIO73NB1	72	1336	Bank1
	A_0[3]	AN27	B1/CCC_NE_PLL	72	1336	Bank1
	A_0[4]	AN26	HSIO76NB1	72	1336	Bank1
	A_0[5]	AP25	HSIO76PB1	72	1336	Bank1
	A_0[6]	AL25	HSIO77NB1	72	1336	Bank1
	A_0[7]	AK25	HSIO77PB1	72	1336	Bank1
	A_0[8]	AJ23	HSIO79NB1	72	1336	Bank1
	A_0[9]	AJ23	B1/CCC_NE_PLL	72	1336	Bank1
	A_0[10]	AJ25	HSIO81NB1/DQ5	72	1336	Bank1
	A_0[11]	AJ24	/DQ5/CCC_NE_P	72	1336	Bank1
	A_0[12]	AL22	HSIO82NB1	72	1336	Bank1
	A_0[13]	AK23	HSIO82PB1	72	1336	Bank1
	A_0[14]	AL24	HSIO83NB1	72	1336	Bank1
	A_0[15]	AL23	HSIO83PB1	72	1336	Bank1
BA0	BA_0[0]	AE25	HSIO84PB1	72	1336	Bank1
BA1	BA_0[1]	AD23	HSIO85NB1	72	1336	Bank1
BA2	BA_0[2]	AD25	HSIO84NB1	72	1336	Bank1
CAS_N	CAS_N_0	AF25	HSIO86NB1	72	1336	Bank1
CK0	CK0_0	AP26	/DQ5/CCC_NE_P	72	1336	Bank1
CK0_N	CK0_N_0	AP27	HSIO79NB1/DQ5	72	1336	Bank1
CK1	Unassigned	AM25	E_CLKIN_N_10/C	72	1336	Bank1
CK1_N	Unassigned	AM26	HSIO74NB1	72	1336	Bank1
CKE0	CKE_0	AF22	HSIO87PB1/DQ5	72	1336	Bank1
CKE1	Unassigned	AD24	HSIO89PB1	72	1336	Bank1
CS0_N	CS_N_0	AE22	HSIO87NB1/DQ5	72	1336	Bank1
CS1_N	Unassigned	AH24	CCC_NE_CLKIN_P	72	1336	Bank1
DM0	DM[0]	AN23	HSIO95NB1	72	1336	Bank1
DM1	DM[1]	AL20	HSIO101PB1	72	1336	Bank1
DM2	Unassigned	AK18	HSIO107NB7	72	1336	Bank7
DM3	Unassigned	AL14	HSIO113NB7	72	1336	Bank7
DM4	Unassigned	AD19	HSIO119NB7	72	1336	Bank7

7. XCVR View [\(Ask a Question\)](#)

The XCVR View allows the user to make assignments for Transceiver Lanes, Reference Clocks and Transmit PLLs. It presents the following views:

- A schematic view of the Reference Clock (REFCLK), the TransmitPLL, and the Transceiver Lanes they drive. See [Figure 7-1](#).
- A graphical placement view of the REFCLK, its connection from the PADS, to the TransmitPLL, to the Transceiver Lanes. See [Figure 7-2](#).
- A Signal Integrity View for a Transceiver Lane, showing TX Emphasis Amplitude, TX Impedance, TX Transmit Common Mode Adjustment, RX and TX Polarity, RX Insertion Loss, RX CTLE, RX Termination, RX P/N Board Connection, and RX Loss of Signal Detector (Low and High). See [Figure 7-3](#).

Figure 7-1. XCVR Interface—Schematic View





Figure 7-2. XCVR Interface—Graphical Placement View



The screenshot displays the Signal Integrity View in a PCB design tool. The left pane shows a hierarchical tree of components, including D084, D083, and a 'Dedicated Ports' section. The main area displays a schematic diagram of the signal path, showing connections between various components and ports. The right pane shows the 'Signal Integrity View' settings for the selected port, including 'PCIE5_LANE_TX00_P/N', 'Tx Emphasis Amplitude', 'Tx Impedance', 'Tx Transient Common Mode Adjustment', and 'RX CTLE'.

- TX Emphasis Amplitude
- TX Impedance
- TX Transmit Common Mode Adjustment
- RX and TX Polarity, RX Insertion Loss, RX CTLE
- RX Termination
- RX P/N Board Connection
- RX Loss of Signal Detector (Low, High, Calibration, and CDR Gain)

To make XCVR Interface I/O assignment, use the XCVR view in the I/O Editor to make assignment in the following order:

- ## 7.2. Direct Versus Cascaded Connection [\(Ask a Question\)](#)

The two types of connections between the reference clock and the TX_PLL and Transceiver lanes are as follows:

- Direct connections are used when the reference clock pin and the TX_PLL or the Transceiver lanes are in the same Quad location. Cascaded connections are used when the reference clock pin and the TX_PLL or the Transceiver lanes are not in the same quad location. Cascade connections are only available going from the top of the device towards the bottom. The cascaded connection is denoted in the XCVR view by the black vertical line down the middle of the placement view.

Note: A REFCLK can connect to all the lanes beside or below it in any quad (down the cascade path) but not those above it (up the cascade path).

The red lines denote cascaded REFCLK connection to the TX_PLL and the Transceiver lanes in the quad.


Connection/Assignment up the Cascade path (from REFCLK to TX_PLL and Transceiver lanes which are above the REFCLK) are illegal and indicated by red lines in the XCVR view.

Each Reference Clock (REFCLK) has a direct dedicated connection to its corresponding TX_PLL and to the lane that the TX_PLL drives in the same quad.

Selecting a dedicated connection or a cascaded connection depends on the trade-off you want to make. A direct dedicated connection from the REFCLK to the TX_PLL gives better signal integrity for the Transceiver whereas a cascaded connection reduces external components and reduces overall power.


The following figure shows direct dedicated path and cascade path.

Figure 7-4. Direct Dedicated Path and Cascade Path



The following figure shows XCVR view.


Figure 7-5. XCVR View



7.3. Reference Clock (REFCLK) I/O Assignments [\(Ask a Question\)](#)

To make I/O assignments, click and drag the REFCLK pin from the Schematic View to the pin location you desire in the Graphical Placement View. If the assignment is legal (no DRC violations), green lines appear to denote the accepted connection between the REFCLK pin through the Q(x)_TXPLL_SSC to the Transceiver lanes.


Figure 7-6. Legal and Accepted Reference Clock I/O Assignment



If the I/O assignment violates the DRC rule, the assignment is not accepted. Red arrows denotes DRC violations. The following figure shows two illegal assignments:


- From the Reference Clock (REFCLK) to the Lanes (Red arrow from REFCLK to the Q2_Lane0)
- From the Transmit PLL to the lanes (Red arrow from TXPLL_SSC to Q2_Lane0)

Figure 7-7. Illegal I/O Assignment



An error message appears in the Log window to identify the DRC rules violated. In this case, there is no feasible dedicated connection from the REFCLK to the Lane and from the Transmit PLL to the Lanes.

Figure 7-8. Log Window Message




Note: I/O assignments can be made for REFCLK, TXPLL, and Transceiver Lanes for all Transceiver protocols except the PCIe Protocol. For the PCIe Protocol, Transceiver Lanes are assigned to predefined locations and cannot be removed.

7.4. Transmit PLL Assignment [\(Ask a Question\)](#)


Drag and drop the Transmit PLL instance into the desired location. Illegal locations are flagged with error messages in the Log window and the illegal connections are indicated by red lines.

Figure 7-9. Illegal Transmit PLL to Lane Assignment



The Log window displays two error messages about the illegal assignments, one for each illegal connection. In this case, the assignment is illegal because there are no feasible dedicated connections.

Figure 7-10. Log Window



7.5. Placement DRC Rules [\(Ask a Question\)](#)

The I/O Editor enforces the DRC rules when Transceivers are placed. Any illegal connection is highlighted as a red line in the Placement View and a corresponding message is displayed in the Log window.

Lane assignments are always legal. DRC rules are enforced for the following:

- Connection from Transmit PLL (TXPLL) to the Lanes
- Connection from the Reference Clock (REFCLK) to the Transmit PLL (TXPLL)

- Connection from the Reference Clock (REFCLK) to the Lanes

7.5.1. DRC—TXPLL to LANES Connectivity [\(Ask a Question\)](#)

A TXPLL_SSC can connect to all the lanes of a quad (shown in brown lines in the Placement View).

Figure 7-11. TXPLL Connection To All Four Lanes Before Placement





Figure 7-12. TXPLL Connection To All Four Lanes After Placement



A TXPLL (non-SSC) can connect to two lanes beside it normally (shown in blue lines in the Placement View).

Figure 7-13. TXPLL Connection To Two Lanes (Before Placement)




Figure 7-14. TXPLL Connection To Two Lanes (After Placement)







Figure 7-15. Q1_TXPLL1 to Four Lanes Connection (Before Placement)**Figure 7-16. Q1_TXPLL1 to Four Lanes Connection (After Placement)****7.5.2. DRC—REFCLK to TXPLL Connectivity** [\(Ask a Question\)](#)


A REFCLK can connect to all the TXPLLs beside and below it (down the Cascade Path) in the Placement View. A REFCLK cannot connect to a TXPLL above it (up the Cascade Path).

A cascade path (represented by the vertical line beside the REFCLKs) is used for the REFCLK to connect to all the TXPLLs below it and the Lanes below it in the Placement View.

Figure 7-17. Illegal Connection From REFCLK to TXPLL Up the Cascade Path**7.5.3. REFCLK to Lanes Connectivity** [\(Ask a Question\)](#)

The REFCLK of a quad can connect to all Lanes of the TXPLL (in addition to that which the REFCLK can connect), as well as all the other Lanes below it (including from different quads). Connection up the Cascade path is illegal.

Green arrows indicate legal connection and red arrows indicate illegal connection from the REFCLK to the Lanes.

Figure 7-18. REFCLK to Lanes Connection—Legal (Down the Cascade Path) and Illegal (Up the Cascade Path)

Green indicates legal placements, and red indicates illegal placements. Illegal assignments are not allowed.

8.2. DRC Rules [\(Ask a Question\)](#)

The I/O Editor enforces the following list of common Design Rules Check (DRC) rules:

- All I/Os of the same logical lane must be placed within the same physical lane.
- For any one physical lane, only one logical lane is allowed to be placed.
- Non-logical lane I/Os can be placed in any physical lane.
- For RGMII Interface, the *_RXC port must be placed on the CLKIN_S_* side of the physical lane.
- When the CDR is placed in a physical lane, the DQS_N slot is reserved and is not available for I/O placement.


For more information on DRC rules for the IOD I/O placement, see the [PolarFire FPGA and PolarFire SoC FPGA User I/O User Guide](#).

9. Floorplanner View [\(Ask a Question\)](#)

The Floorplanner View displays all design elements in one window. The selections you make in the views are reflected in the window. The color scheme used in the canvas is dependent on the layers and colors you have selected in the Display Options window.

The following figure shows the Floorplanner View.

Figure 9-1. Floorplanner View



9.1. Operating Modes [\(Ask a Question\)](#)

The Floorplanner View has two operating modes. Click the **Macro Manipulation Mode** button to switch between Macro Manipulation Mode and Region Manipulation modes:

- **Macro Manipulation Mode.** Use this mode to work with macros, such as assigning macros to location or unassigning placed macros from locations. You can also view properties of selected macros in the Floorplanner View from the properties window. You can select multiple macros by pressing the **CTRL** key and selecting required macros.
- **Region Manipulation Mode.** Use this mode to work on regions such as resizing, renaming, or deleting regions, or assigning and unassigning macros or nets to regions.

9.1.1. Display Modes [\(Ask a Question\)](#)

The Display Options window allows you to customize the layout and the color settings for design elements on the Floorplanner View to meet your personal preferences.

There are three default layers and colors settings group:

- System
- Pin_Planner
- Grey_Scale

You can also see the colors for different component types (nets, modules, pins, and so on) in the Display Options window.

9.1.1.1. Selection [\(Ask a Question\)](#)

Clicking an item selects that one object in the model. However, you can select multiple items:

- To select contiguous items, click the first item you want to select, and then hold down the Shift key and click the last item you want to select. All items between the two are selected automatically.

- To select items that are not contiguous. click the first item. Then hold down the Ctrl key and click each additional item you want to select.

If you selected multiple items and then change your mind about a selected item, you can deselect the item by holding down the Ctrl key and clicking the item.

Selections follow a symmetrical behavior: If you select a port, all macros attached to it are selected as well. Similarly, if you select a pin object, all corresponding macro objects are also selected.

For example, if you select a port, the macro is also shown as selected. However, the property page still points to the port. Pin selection follows the same behavior.

9.1.1.2. Highlighting [\(Ask a Question\)](#)

The Highlighting option allows you to set persistent colors on designated macros, nets, or both across the system.


To set a highlight, go to the **Logical Object Browser** or the **Net Object Browser**, select one or more macros and/or components, and click the pencil icon as shown in the following toolbar.

Figure 9-2. Pencil and Eraser Icons



When you set a highlight, all selected macros, ports, and/or nets in the design are marked with the selected color. The selected color appears in the left object browser tree. The following figure shows the left Main Object Browser with the logical tree displayed. To select both components, click one component, hold down the Ctrl key and click the other component.

Figure 9-3. Example of Highlighting Shown in the Object Browser Tree



The color remains until you select one of the two middle eraser icons:

- The left eraser icon removes all highlights.
- The right eraser icon removes highlights only from selected items.


To set the highlights, use the **Current Highlight** check box from the **Design Settings** docking window. Below this check box are an **Auto Rotate** check box, along with eight **Highlight** check boxes and radio buttons.

- Use the **Highlight** check boxes to enable or disable a highlight. Separate check boxes are provided for macros and nets.

- Use the **Highlight** radio buttons to designate which highlight is active.


Note: You cannot disable the active highlight.

Figure 9-4. Design Settings Docking Window



Clicking the colored box next to each check box allows you to select a color for that macro or net. The following figure shows an example of the results when all options under **Nets** are exposed.

Figure 9-5. Example of Exposing All Nets



If **Net Settings** is not checked, all nets in the system, except cross-probe nets, are disabled. All options subordinate to that option are marked with a gray box to show that the option is not used. If **Show Nets for Highlighted Macros** is not checked, all net options inside the currently highlighted net selections are disabled. To restore the color of these options, check the individual options. If you check **Show Nets for Highlighted Macros**, the individual settings in the highlight settings area determine whether nets will be drawn.

Note: If you enable **Auto Rotate** and **Net** under **Auto Rotate**, and then uncheck the check box in the **Net** color selection, the net color in the Net view is not consistent with that of the Planner.

The **Consolidate Globals** option converts the raw clock display with globals connected to locals as if the sum of the local nets and the global nets are the same net. This is for display purposes only. The bottom three options in the Design Settings docking window work with groups of macros and ports for which you consider net lines as a single entity:

- **Show Interior Nets for Selected/Highlighted Macros** shows lines that connect two different macros in the group.
- **Show Input Nets for Selected/Highlighted Macros** shows lines that connect an output port of an exterior macro to one or more input pins in the group.
- **Show Driver Nets for Selected/Highlighted Macros** shows drivers in the group that connect with an exterior macro.

9.1.1.3. Cross Probing [\(Ask a Question\)](#)

When an external application performs a cross probe, the elements colored for cross probing and cross probe nets are always displayed. There are no options that allow cross probing to be disabled or turned off; however, you can change the cross probing color to transparent.

Any additional cross probes get added to the current ones. To clear a cross probe state, use the rightmost eraser icon in the following toolbar.

Figure 9-6. Pencil and Eraser Icons




9.1.2. Floorplanner View Icons [\(Ask a Question\)](#)

The icons available across the top of the Floorplanner View window allows you to zoom in, zoom out, assign I/O banks, runs DRC checks, and create regions for placement.

The following figure shows floorplanner view icons.

Figure 9-7. Floorplanner View Icons



The following table lists the functions of each icon.

Table 9-1. Floorplanner View Icons

Icon	Name	Function
	Rubber Band Zoom	Rubber Band Zoom - Drags out an area to enlarge/zoom into.
	Rubber Band Select	Rubber Band Select an area to Zoom into. Click in the Floorplanner View and drag the mouse to delineate an area. Release the mouse and all macros inside the delineated area are selected. Works in the Macro Manipulation Mode.
	Zoom In	Zoom In to canvas.
	Zoom Out	Zoom Out of canvas.
	Zoom to Fit	Zoom to fit the canvas size.
	Zoom to Location	Zoom to a Location Specified by X-Y co-ordinates.

Table 9-1. Floorplanner View Icons (continued)

Icon	Name	Function
	Zoom to fit Selection	Zoom to fit selected macros and ports. When enabled, the view attempts to center the view on the selected and placed ports.
	Check Design Rules	Run the Prelayout Checker, a preliminary check of the netlist for possible Place and Route issues.
	Check DRC Rules for Selected Interfaces	Check the DRC Rules for selected interfaces.
	I/O Bank Settings	Set the I/O bank to specific I/O Technology.
	Auto Assign I/O Bank	Run the Auto I/O Bank and Globals Assigner. Assigns a voltage to every I/O Bank that does not have a voltage assigned to it and if required, a VREF pin.
	Collapse Visible Views	Collapse the visible views.
	Expand Selected Items in Visible Views	Expand selected Items in the visible views.
	Create Empty	Create an empty user region.
	Create Inclusive	Create an inclusive user region.
	Create Exclusive	Create an Exclusive user region.
	Delete	Delete the selected user region.
	Show Nets For Macros	Show all nets connected to the macro. There are often many nets attached to the macro, and it is off by default.

An object or a collection of the objects in the Design View window can be selected and placed in any location that is legal.


The following figure shows an example of a successful placement into the Floorplanner View.

Figure 9-8. Floorplanner View—Successful Placement



The following figure shows an example of an unsuccessful placement attempt into the Floorplanner View.

Figure 9-9. Floorplanner View - Unsuccessful Placement Attempt




9.1.3. Region Assignments [\(Ask a Question\)](#)

When you right click an item in one of the tabs in the Main Object Browser, you can choose from available options, which can include placing an item to a location, unplacing an item from a location, locking the placement, and assigning a region.


Multiple items can be selected and assigned to the same region at the same time. You can also select a region assignment by right clicking an item and choosing **Region Assign**. The dialog box opens as shown in the following figure. This option is not available for objects in the Region tab.

Figure 9-10. Select Region Dialog Box



The progress of All Region Assign and Unassign commands is as shown in the following figure.

Figure 9-11. Progress of All Region Assign and Unassign Commands



Note: This dialog shows only the progress, and does not allow the user to cancel the operation. Closing the dialog does not terminate the operation.

9.2. Netlist Views [\(Ask a Question\)](#)

Two windows are available for viewing the netlist (a schematic view of the design used to trace the nets and debug) of the design.

- Post-Synthesis Hierarchical View (Netlist Viewer - Hier)
- Post-compile flattened Netlist View (Netlist Viewer - Flat)


Separate tabs for Hierarchical View and Flattened Netlist View make it easy to switch between the different views.

9.2.1. Netlist Viewer—Hier [\(Ask a Question\)](#)

The Post-Synthesis Hierarchical View (Netlist Viewer—Hier) is a hierarchical view of the netlist after synthesis and after technology mapping to the Microchip FPGA technology. Click on the Canvas to load the "Hierarchical view" in Netlist Viewer—Hier. The Chip Planner loads the netlist into the system memory and displays it in the window.

When the netlist is loaded for the first time into memory, a pop-up progress bar indicates the progress of the loading process, which may incur some runtime penalty for a large netlist.


Figure 9-12. Netlist Viewer—Hier View



9.2.2. Netlist Viewer—Flat [\(Ask a Question\)](#)

This is the flattened (non-hierarchical) netlist generated after synthesis, technology mapping and further optimization based on the DRC rules of the device family and/or die. Click on the Canvas to load the "Flat" view in the Netlist Viewer—Flat window. The Chip Planner loads the netlist into the system memory and displays it in the window as shown in the following figure.

Figure 9-13. Netlist Viewer—Flat View (Flattened Netlist)



9.2.2.1. Display Across Multiple Pages [\(Ask a Question\)](#)

Hierarchical or flattened netlists can span multiple pages, in which case the first page is displayed when it opens.

The current page number and the total number of pages are displayed in the status bar at the lower right corner of the window.

Figure 9-14. Status Bar



To go to different pages of the Netlist view, use the left-pointing arrow:



or the right-pointing arrow:



9.2.3. Netlist Viewer Features [\(Ask a Question\)](#)

See the [Netlist Viewer User Guide](#) for details about Netlist Viewer features.

9.2.4. Chip Planner Features [\(Ask a Question\)](#)


See the [Chip Planner User Guide](#) for details about Chip Planner features.

10. Other I/O Editor Windows [\(Ask a Question\)](#)

10.1. World View Window [\(Ask a Question\)](#)

The World View shows a red rectangle which reflects what is visible in the Floorplanner View in the context of the die. Changing what is visible in the canvas also changes the red rectangle. Changing the size or position of the red rectangle changes what is seen in the Floorplanner View.


Figure 10-1. World View Window



10.2. Log Window [\(Ask a Question\)](#)

The Log window displays all messages generated by I/O Editor. You can filter the messages according to the type of message: Error, Warning, and Info. If you have made and saved changes in I/O Editor, the Log window displays the name and location of the PDC file(s) which have been edited/updated to reflect the changes.

Figure 10-2. Log Window




10.3. Object Window [\(Ask a Question\)](#)

The Object window (Main Object Browser) includes the following tabs:

- Port
- Logical
- Net
- Region

Press **Ctrl+F** to open a floating window for the active tab. See the following example.

Figure 10-3. Floating Object Window Tab Example

The following table lists the Object window icons.

Table 10-1. Object Window Icons

Description
Collapse everything in the tree.
Expand selected.
Clear the filter and refresh the tree reflecting no filters.
Change sort order and allow additional filtering.

10.4. Display Options Window [\(Ask a Question\)](#)

The Display Options window configures the display of the selected view. Three display options are available as follows:

- Fill Device Cells
- Use Cluster Mode
- Consolidate Globals

10.5. Properties Window [\(Ask a Question\)](#)

The Properties window displays the properties of the design elements. What is displayed in the Properties window is dependent on what is selected in the design view. Properties displayed may include the following, depending on the type of design elements:


- Macro/Component Name—Full Macro or component name based on selection.
- Cell Type—Resource type based on design element selection.
- Placed (Location)—X-Y coordinates where device element is placed.
- Resource Usage Table—A table showing resources based on component and macro selection.
- Region Attached Table—A table showing region to which selected macro/component is assigned.
- User region (if any) to which it is attached.
- Nets Table—A table showing pins and nets which is associated with the selected macro along with fanout value.
- Locked/Unlocked (Placement)—The selected port is locked or unlocked.
- Port—Port name to which the I/O macro is assigned (only shown for I/O port macros).
- I/O Technology Standard—I/O Technology which is associated with the selected I/O macro (only shown for I/O port macros).
- I/O Bank—I/O bank to which the selected I/O macro is assigned (only shown for I/O port macros).
- Pin (Package Pin)—Pin to which the macro is assigned (only shown for I/O port macros).

Not all properties in the list are displayed. The list of displayed properties varies with the type of design element selected.

11. Export Physical Constraints (PDC) [\(Ask a Question\)](#)


The I/O Editor allows you to export the physical constraints (I/O Constraints and Floorplan Constraints) of the design in a PDC file to any file location on your disk. You can export the User constraints or the Full constraints of the design. The I/O PDC files can be exported (**File > Export Physical Constraint (PDC) > I/O Constraint**), as shown in the following figure.

Figure 11-1. Export I/O Constraints PDC File Dialog Box



The fp.pdc file can be exported (**File > Export Physical Constraint (PDC) > Floorplan Constraint**), as shown in the following figure.

Figure 11-2. Export Floorplanner Constraints PDC File Dialog Box



12. Appendix [\(Ask a Question\)](#)

This section describes the support for the PolarFire SoC MSS I/Os in the I/O Editor in Libero SoC v12.5.

12.1. MSS I/O Placement [\(Ask a Question\)](#)

MSS I/O placement is done automatically as each port of the MSS has a fixed location on the package.

12.2. Bank Settings [\(Ask a Question\)](#)

The following table lists bank settings.

Table 12-1. Bank Settings

Type of Bank	Bank Name	Supported Voltages
MSS_IO Peripheral I/Os	Bank2	VDDI = 1.2 VDDI = 1.5 VDDI = 1.8 VDDI = 2.5 VDDI = 3.3
MSS_IO Peripheral I/Os	Bank4	VDDI = 1.2 VDDI = 1.5 VDDI = 1.8 VDDI = 2.5 VDDI = 3.3
MSS_SGMII_IO RefClk and SGMII I/Os	Bank5	VDDI = 2.5 VDDI = 3.3
MSS_DDR_IO DDR I/Os	Bank6	DDR3, VDDI = 1.5 DDR3L, VDDI = 1.35 DDR4, VDDI = 1.2 LPDDR3, VDDI = 1.2 LPDDR4, VDDI = 1.1

12.3. IOSTD Support per Type of Bank [\(Ask a Question\)](#)

The following table lists the IOSTD support per type of bank.

Table 12-2. IOSTD Support per Type of Bank

Bank Type	IOSTDs
MSS_IO	LVC MOS12 LVC MOS15 LVC MOS18 LVC MOS25 LVC MOS33

Table 12-2. IOSTD Support per Type of Bank (continued)

Bank Type	IOSTDs
MSS_SGMII_IO	LVTTTL PCI LVCMOS33 LVCMOS25 LVCMOS18 SSTL25I SSTL18I LVDS25 LVPECL33 LVDS33 RSDS25 RSDS33 MINILVDS25 MINILVDS33 SUBLVDS25 SUBLVDS33 PPDS25 PPDS33 LCMD525 LCMD533
MSS_DDR_IO	SSTL15I SSTL135I POD12I HSTL12I HSUL12I LVSTL11I

12.4. Port IOSTD Settings [\(Ask a Question\)](#)

The following table shows how I/O standards are computed.

Table 12-3. IOSTD Support per Type of Bank

Ports	IOSTDs
Peripherals on Bank4	1.2: LVCMOS22 1.5: LVCMOS15 1.8: LVCMOS18 2.5: LVCMOS25 3.3: LVCMOS33
Peripherals on Bank2	1.2: LVCMOS22 1.5: LVCMOS15 1.8: LVCMOS18 2.5: LVCMOS25 3.3: LVCMOS33
REFCLK on Bank5	LVTTTL PCI LVCMOS33 LVCMOS25 LVCMOS18 SSTL25I SSTL18I LVDS25 LVPECL33
SGMII on Bank5	LVDS25 LVDS33 RSDS25 RSDS33 MINILVDS25 MINILVDS33 SUBLVDS25 SUBLVDS33 PPDS25 PPDS33 LCMD525 LCMD533

Table 12-3. IOSTD Support per Type of Bank (continued)

Ports	IOSTDs
DDR IOs on Bank6	DDR3: SST115I DDR3L: SSTL135I LPDDR3: HSUL12I LPDDR4: LVSTL11I DDR4 DQ/DQS/DM: POD12I

12.5. Updating the I/O Banks and IOSTD [\(Ask a Question\)](#)

Users cannot update the I/O Bank setting or IOSTD of the MSS I/Os.

These settings apply to the software side in the XML. They do not affect the Libero project and are for the user's reference in ready-only format.

12.6. Designs without an MSS Macro [\(Ask a Question\)](#)

For designs without an MSS macro, the banks are not set and unlocked. Users can change the values, but the changes will not affect anything.

12.7. Default Bank Settings [\(Ask a Question\)](#)

If there is an MSS macro in the design and some interfaces are not used, this is the default bank settings that will be used.

Table 12-4. Default Bank Settings

Banks	Default Value
Bank2	VDDI = 3.3
Bank4	VDDI = 3.3
Bank5	VDDI = 3.3
Bank6	VDDI = 1.5

12.8. PDC Setting [\(Ask a Question\)](#)

A PDC file is not needed for these I/Os because the settings from the MSS Configurator are being used. If the user specifies a correct placement and I/O standard, the tool will accept the user's settings and will not error-out. But if the user tries to set any of the other specific MSS I/O attributes, it will fail. These constraints will not be written in the generated PDC file from the Chip Planner.

12.9. PolarFire SOC MSS I/O Attributes [\(Ask a Question\)](#)

These I/O attributes are valid only for MSS I/Os and are read only in the I/O Editor. These MSS I/O attributes appear on the right side of the default I/O attributes and will be visible even when there is no MSS being used in the design.

Reference Clock

The following table lists the MSS I/O attributes in the I/O Editor for Reference CLK.

Table 12-5. MSS I/O Attributes and Values for Reference CLK

MSS I/O Attributes	Values
MSS Resistor Pull	None, Up
MSS Clamp Diode	OFF, ON
MSS Persist	OFF, ON
MSS User I/O Lock Down	OFF, ON
MSS Odt (Ohm)	OFF, 100
MSS Thevenin (Ohm)	OFF, 150, 75, 50

Table 12-5. MSS I/O Attributes and Values for Reference CLK (continued)

MSS I/O Attributes	Values
MSS Schmitt Trigger	OFF, ON

Peripheral I/Os

The following table lists the MSS I/O attributes in the I/O Editor for Peripheral I/Os.

Table 12-6. MSS I/O Attributes and Values for Peripheral I/Os

MSS I/O Attributes	Values
MSS Resistor Pull	None, Up, Down, Hold
MSS Clamp Diode	OFF, ON
MSS Persist	OFF, ON
MSS User I/O Lock Down	OFF, ON
MSS Schmitt Trigger	Schmitt Trigger is always ON for 1.2, 1.5 and 1.8 V I/O Bank values. Otherwise, it can be either ON or OFF. The MSS Schmitt Trigger can have the following values: OFF, ON
MSS Low Power Mode Input Receiver	OFF, ON
MSS Low Power Mode Output Buffer	OFF, ON
MSS Output Drive (mA)	1.5, 2, 3, 3.5, 4, 6, 8, 10, 12, 16, 20, 24, 27, 30, 34, 40, 48, 60

DDR I/Os

The following table lists the MSS I/O attributes in the I/O Editor for DDR I/Os.

Based on the memory type used, the memory types have the following values.

Table 12-7. ODT DQ and ODT DQS Ports

Memory Type	Value
DDR3/DDR3L	120, 60, 40, 30
DDR4	120, 80, 60, 40, 30
LPDDR3	240, 120, 80, 60, 40, 30
LPDDR4	120, 80, 60, 48, 40

Table 12-8. Outdrive for DQ and DM Ports, DQS Ports, CLK Ports, ADD/CMD Ports

Memory Type	Value (mA)
DDR3/DDR3L	48, 34, 30, 24
DDR4	60, 48, 34, 27
LPDDR3	60, 48, 40, 34
LPDDR4	60, 48, 40, 34

SGMII I/Os

The following table lists the MSS I/O attributes in the I/O Editor for SGMII.

Table 12-9. MSS I/O Attributes and Values for SGMII

MSS I/O Attributes	Values
MSS Resistor Pull	None, Up, Down, Hold
MSS Odt (Ohm)	OFF, 100
MSS Vcm Input Range	MID, LOW
MSS Source Termination (Ohm)	OFF, 100
MSS Output Drive (mA)	1.5, 2, 3, 3.5, 4, 6

13. Revision History [\(Ask a Question\)](#)

The revision history describes the changes that were implemented in the document. The changes are listed by revision, starting with the most current publication.

Revision	Date	Description
P	05/2025	The following list of changes is made in revision P of the document: Revised section Slew.
N	08/2024	This document is released with Libero SoC Design Suite v2024.2 without changes from v2024.1.
M	02/2024	This document is released with Libero SoC Design Suite v2024.1 without changes from v2023.2.
L	08/2023	Editorial changes. No technical content updates.
K	08/2023	Editorial changes. No technical content updates.
J	04/2023	This document is released with Libero SoC Design Suite v2023.1 without changes from v2022.3.
H	12/2022	This document is released with Libero SoC Design Suite v2022.3 without changes from v2022.2.
G	08/2022	This document is released with Libero SoC Design Suite v2022.2 without changes from v2022.1.
F	04/2022	This document is released with Libero SoC Design Suite v2022.1 without changes from v2021.3.
E	12/2021	The following list of changes is made in revision E of the document: - Updated section User I/O Lock Down for Port View and Pin View. - Added a note for I/O State in Flash*Freeze Mode and I/O Available in Flash*Freeze Mode for Port View and Pin View.
D	08/2021	The following list of changes is made in revision D of the document: Updated section DRC Rules.
C	08/2021	This document is released with Libero 2021.2 SoC Design Suite without changes from v2021.1.
B	04/2021	The following list of changes is made in revision B of the document: Added Use I/O Calibration from the Lane section.
A	11/2020	Document is converted to Microchip format.
8.0	03/2020	The following list of changes is made in revision 8.0 of the document: - Revised the memory assignments for Memory View to examples such as DDR3/4, LPDDR3, and QDR - Revised the supported memory types to DDR3, DDR4, LPDDR3, and QDRI+
7.0	12/2019	The following list of changes is made in revision 7.0 of the document: Updated Resistor Pull information.
6.0	08/2019	The following list of changes is made in revision 6.0 of the document: Updated to reflect latest software changes and added a new chapter about Export Physical Constraints (PDC).
5.0	12/2018	The following list of changes is made in revision 5.0 of the document: Updated document template and edited and updated text.
4.0	05/2018	The following list of changes is made in revision 4.0 of the document:: - Updated I/O information for Port and Pin Views. - Made minor edits for clarification about Package, XCVR, IOD, and Floorplanner Views.

Revision History (continued)

Revision	Date	Description
3.0	10/2017	The following list of changes is made in revision 3.0 of the document:: • Added new chapter about Floorplanner View. • Added new chapter about other windows. • Updated I/O attribute information. • Updated figures to reflect new tab order and naming. • Added information about Signal Integrity View.
2.0	05/2017	The following list of changes is made in revision 2.0 of the document: • Updated Memory View and IOD View and updated graphics.
1.0	01/2017	Initial Revision

Microchip FPGA Support

Microchip FPGA products group backs its products with various support services, including Customer Service, Customer Technical Support Center, a website, and worldwide sales offices. Customers are suggested to visit Microchip online resources prior to contacting support as it is very likely that their queries have been already answered.

Contact Technical Support Center through the website at www.microchip.com/support. Mention the FPGA Device Part number, select appropriate case category, and upload design files while creating a technical support case.

Contact Customer Service for non-technical product support, such as product pricing, product upgrades, update information, order status, and authorization.

- From North America, call **800.262.1060**
- From the rest of the world, call **650.318.4460**
- Fax, from anywhere in the world, **650.318.8044**

Microchip Information

Trademarks

The “Microchip” name and logo, the “M” logo, and other names, logos, and brands are registered and unregistered trademarks of Microchip Technology Incorporated or its affiliates and/or subsidiaries in the United States and/or other countries (“Microchip Trademarks”). Information regarding Microchip Trademarks can be found at <https://www.microchip.com/en-us/about/legal-information/microchip-trademarks>.

ISBN: 979-8-3371-1122-3

Legal Notice

This publication and the information herein may be used only with Microchip products, including to design, test, and integrate Microchip products with your application. Use of this information in any other manner violates these terms. Information regarding device applications is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. Contact your local Microchip sales office for additional support or, obtain additional support at www.microchip.com/en-us/support/design-help/client-support-services.

THIS INFORMATION IS PROVIDED BY MICROCHIP “AS IS”. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, OR WARRANTIES RELATED TO ITS CONDITION, QUALITY, OR PERFORMANCE.

IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL LOSS, DAMAGE, COST, OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE INFORMATION OR ITS USE, HOWEVER CAUSED, EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP’S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THE INFORMATION OR ITS USE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THE INFORMATION.

Use of Microchip devices in life support and/or safety applications is entirely at the buyer’s risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip products:

- Microchip products meet the specifications contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is secure when used in the intended manner, within operating specifications, and under normal conditions.
- Microchip values and aggressively protects its intellectual property rights. Attempts to breach the code protection features of Microchip products are strictly prohibited and may violate the Digital Millennium Copyright Act.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of its code. Code protection does not mean that we are guaranteeing the product is “unbreakable”. Code protection is constantly evolving. Microchip is committed to continuously improving the code protection features of our products.